



How to Use a Transom Strap

1. Secure a hook from one strap-end to the left or right eyelet on the transom.
2. Pull the strap down to your trailer's frame.
3. Slide the other hook through the closest mounting tab on your trailer or hook it under/around the frame edge.
4. Tighten the strap buckle or ratchet-style handle as needed.
5. Attach the second strap to the opposite side then wrap the buckles or handles on the strap with boat buckle pads.

Tips & Warnings:

- Never over-tighten your transom straps as doing so can damage not only your boat, but also the box portion of the retractable strap unit (if applicable).
- Never position your straps across sharp edges of the boat/trailer as natural friction and shifting caused during transport can cause any edges to rub across the straps---tearing at the strap webbing or thread weave. This tearing can eventually cause a strap to break and your boat to slide or bounce on the trailer, resulting in damage.
- Always recheck the tension of your transom straps during transport of your boat as the craft can often settle on the trailer frame during travel, causing the straps to loosen. Recheck the straps after the first three miles of a trip then approximately every 25 to 30 miles thereafter.